

## Items Supplied >

- 4 - 5/16" x 3/4" Bolts
- 4 - 5/16" Nuts
- 4 - 5/16" Lock Washers
- 1 - 8mm x 35mm Bolt
- 1 - 8mm Flat Washer
- 1 - 8mm Spring Washer

## Application >

VT1100 AERO 98-02

## Instruction Manual >

01-1122

Page 1 of 1

1. Hold your Freeway Bar into position so that the brackets at the top with two holes in it aligns with the two holes up by your steering head. Note where the bottom mounts will bolt into place. Remove the lower bolts from the freeway bar bottom mounting position.
2. Drill out the two existing holes at the top of your frame on both sides using a 5/16" drill bit. Bolt the top mounts into place using the supplied 5/16" bolts, lock washers and nuts.
3. Bolt the left side of the freeway bar into place with stock bolt and torque to factory specifications. Bolt the right side of the freeway bar into place using the supplied 8mm x 35mm bolt, 8mm spring washer and flat washer and tighten to factory specifications.

**Cobra Freeway Bars add style to your motorcycle. They are not designed to withstand a serious impact and may not protect you and/or your motorcycle in the event of a crash.**

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*