

Items Supplied >

- 1 - Left Floor Board Assembly
- 1 - Right Floor Board Assembly
- 2 - Extension Plate
- 2 - 8mm x 20mm Bolt
- 4 - 8mm x 16mm Bolt
- 2 - 8mm Flange Nut

Application(s) >

Suzuki Boulevard M109R 06-14

Instruction Manual >

06-3845 / 06-4845

Page 1 of 1

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

Left Side

1. Remove seat
2. Remove lower side body panel from three(3) attachment grommets.
3. Remove two bolts retaining stock foot peg assembly.
4. Bolt on Cobra extension plate using two(2) stock bolts and one(1) each of supplied 8mm x 20mm bolt and flanged nut. *Torque to factory specifications.*
5. Replace body panel.
6. Bolt the Cobra floorboard to the extension plate using the two(2) supplied 8mm x 16mm w/loctite bolts. *Torque to 20 ft lbs or 28 Nm.*

Right Side

1. Remove allen screw from side body panel.
2. Remove plastic rivet from top body panel and pull free from rear retaining grommet.
3. Remove lower side body panel from two(2) attachment grommets.
4. Bolt on Cobra extension plate using two(2) stock bolts and one(1) each of the supplied 8mm x 20mm bolt and flanged nut. *Torque to factory specifications.*
5. Replace lower side body panel and allen bolt.
6. Push top body panel back onto retaining grommet and reinstall plastic rivet.
7. Bolt the Cobra floorboard to the extension plate using the two(2) supplied 8mm x 16mm w/loctite bolts. *Torque to 20 ft lbs or 28 Nm.*
8. Reinstall seat.

*** Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**